







# **USER MANUAL**

Comfort System4<sup>™</sup>
English

## **Contents**

INTRODUCTION	
CENTRAL CONTROLLER - MENU OVERVIEW	2
FIRST TIME SETTINGS Setup of the Comfort System4 <sup>TM</sup> Setup Central Controller Connecting thermostats Assign time schedules Adjust time schedules	( (
CENTRAL CONTROLLER FOR CS4 <sup>TM</sup> General operation Select room	2
OPERATION MODE Holiday mode Comfort mode Frost mode Manual mode	4
CENTRAL CONTROLLER - MENU 4-event settings: Time schedules	
Engineer settings Offset temperature	6
Adaptive function	-

Application	6
Temperature scale	6
Frost temperature	6
Backlight	6
Sensor selection	6
Language	
Factory reset	6
Information	
System settings	
Add unit	6
Remove unit	
Switch unit	
Alarm relay	
Readout	
Energy monitor	
Room status	
CENTRAL CONTROLLER, GENERAL	
	_
Error messages	7
Error messages Control signal input	
Control signal input	7
Control signal input	<b>7</b> 7
Control signal input	<b>7</b> 7 7
Control signal input	<b>7</b> 7 7
Control signal input	<b>7</b> 7 7
Control signal input  Setback.  Frost protection  Off  THERMOSTAT FOR CS4 <sup>TM</sup>	<b>7</b> 7 7 7
Control signal input	<b>7</b> 7 7 7
Control signal input Setback Frost protection Off  THERMOSTAT FOR CS4 <sup>TM</sup> General operation Wireless signal strength	<b>7</b> 7 7 7 <b>7 7 7</b>
Control signal input	7 7 7 7 <b>7</b> <b>7</b> <b>8</b>
Control signal input	<b>7</b> 7 7 7 <b>7 8</b> 8
Control signal input Setback Frost protection Off  THERMOSTAT FOR CS4 <sup>TM</sup> General operation Wireless signal strength Daily use of thermostat 4-event temperature setting (Auto) Local-Manual temperature setting	7 7 7 7 <b>7</b> <b>7</b> <b>8</b> 8
Control signal input	7 7 7 7 <b>7</b> <b>7</b> <b>8</b> 8
Control signal input	7 7 7 7 <b>7</b> <b>7</b> <b>8</b> 8
Control signal input	7 7 7 7 7 8 8 8 8
Control signal input Setback Frost protection Off  THERMOSTAT FOR CS4 <sup>TM</sup> General operation Wireless signal strength Daily use of thermostat 4-event temperature setting (Auto) Local-Manual temperature setting Child Lock  THERMOSTAT, SETUP MENU Menu overview	7 7 7 7 7 8 8 8 8
Control signal input	<b>7</b> 7 7 <b>7 7 7 8</b> 8 <b>8 8</b>

Max. limit temperature.....

Min. limit temperature	8
Measured floor temperature	8
Measured room temperature	8
Application	8
Adjust	
Backlight	9
Address readout	
Repeater function	9
Software version	9
THERMOSTAT, TROUBLESHOOTING	
Factory reset	
Status messages	
Error messages	
Error codes, overview	9
RELAY MODULE FOR CS4™	
General operation	
Application	
Night setback	
Frost protection	
Thermostat with external sensor	
Error messages, LED readouts	
Factory reset	10
HOW TO PLAN YOUR SYSTEM	
Zone-list, names for time schedule	
Table for time schedules	11

## **INTRODUCTION**

Comfort System4™ is a complete control system for multi-room, electric heating systems consisting of up to 32 rooms. The system consists of a Central Controller with Thermostats and Relay modules. The wireless Central Controller and Thermostat with room and/or floor sensor ensures maximum comfort and minimum energy costs.

The Central Controller, MCS4/OCS4-10 is the main thermostat, which controls and monitors all the thermostats and relay modules in the different rooms. All thermostats and relay modules in the Comfort System4™ are programmed from the central controller. Animated menu navigation ensures easy setup, monitoring of energy consumption and selection of comfort mode or holiday mode. The Central Controller has 5 pre-programmed time schedules. For each day of the week, individual temperatures can be set for 4 different periods, called events, all of which can be adjusted to suit

your needs. Lowering the temperature when the home is unoccupied reduces energy costs without reducing comfort.

Furthermore, the Central Controller features an adaptive function

that automatically adjusts heating period start times to ensure that the required temperature is reached at the required time. After 3 days the adaptive function has learned when the heating must be switched on.

The thermostat, MSD4/OSD4-1999 is controlled by the central controller of the CS4<sup>™</sup>. Basic functions can easily be performed locally on the thermostat. Other functions such as 4-event time-program settings can be performed from the Central Controller

The relay module, MSA4/OSA4-10 controlling electric heating panels, etc., featuring night setback, frost protection and floor sensing thermostat mode. The relay module is controlled by the central controller of the  $CS4^{TM}$ .

16:31 / Tue

Comfort System4™

## FIRST TIME SETTINGS Setup of the Comfort System4™

Follow these simple steps to make the system ready for use.

- 1. Setup Central Controller.
- 2. Connect thermostats.

Connect all thermostats and relay modules in the heating system, to the Central Controller.

3. Assign time schedules to the thermostats.

It is a good idea to divide the thermostats/relay modules into groups with the same time schedule. See "How to plan your system" in the back of this manual.

4. Adjust time schedules.

The time schedules can be programmed with week schedules, times and temperatures to suit the specific needs of the different groups/rooms.

## **Setup Central Controller**

The first time you switch the power interrupter to ON "I", basic settings must be set. The menu will automatically guide you through

- 1. Set "language", "time" and "date" with the up and down buttons and confirm with OK.
- 2. "Please select schedule for this thermostat"

Name the time shedule with a specific name from the list called "7one" and confirm with OK

Tip. Note it down in the table in the back of this manual.

3. "Please activate thermostats for connection" You can now connect the thermostats/relay modules in the system to the Central Controller. Confirm with OK.

## Connecting thermostats and relay modules (units)

When you connect a thermostat or a relay module to the Central Controller it is a good idea to make a plan over your system. Go to "How to plan your system" in the back of this manual, and fill out the tables. Write down what room the thermostat/relay module is located in and what address was assigned.

- 1. "Connecting" flashes on the Central Controller. The units can now be turned on one-by-one.
- 2. Switch on the power to the unit. The unit will start connecting to the Central Controller.

"Con" flashes on the thermostat or the "Green LED" flashes quickly on the relay module.

3. "Adr/01" flashes on the thermostat when the connection is ok. Press a button to confirm. "Green LED" is constantly ON on the relay module when the connection is ok. If the relay module is not connecting ("Green LED" flashes slowly), then switch the relay module off and back on again to restart the connection procedure.

"01: Connected" is displayed in the list on the Central Controller when the unit is connected, and "Connecting" flashes to indicate that the Central Controller is ready to connect to the next unit.

Adr

**→** 🗓 (

- 4. Go to the next unit to be connected, and switch on the power. Repeat the procedure until all units in the system are connected.
- 5. The Central Controller will now display a list of all units connected to the system. Use "arrow up/down" to go through the list. "00: Schedule-Name" / "01: Connected" / "02: Connected" etc. The connected units now need to have a time schedule assigned.

Tip. Do not exit this menu, continue to assign time schedules.

## Assign time schedules to the units

After all the units are connected to the Central Controller, they

need to have a time schedule assigned. Up to 5 different time schedules can be programmed in the system.

It is a good idea to divide the units into groups with the same time schedule. You need to name the time schedules from the list (zone names). Remember you can only have 5 time schedules, but you can have many thermostats using the same one.

English

Tip. Use the table at the back of the manual to help you get an overview of the units in the groups (e.g. 01-Bedrooms, 02-Kitchen, 03-living area, 04-bathroom, and 05-Utility).

- 6. Select the thermostat or relay module to change ("01:connected") use "arrow up/down" and confirm with OK.
- 7. Select a name for the time schedule and confirm with OK. You can only have 5 names/zones.

The unit has now been assigned a time schedule. (e.g. "01: Bedrooms").

Tip. Note it down in the table at the back.

8. Continue until all units have been assigned a time schedule. confirm with "Exit" to go to the main menu.

If a unit has been assigned the wrong time schedule, it can be changed in the "Switch unit" menu (Menu/System settings/ switch unit).

Comfort System4<sup>™</sup> is now ready for use and will control your heating system in accordance with the pre-programmed time


NOTE. The 5 time schedules are set at the factory to the same 4-event settings.

## Adjust time schedules

You can now adjust the settings in the 5 time schedules to suit the specific needs of the different groups/rooms.

Go to the section: "Programming of time schedules". Tip! Write down how you want to program the time schedules before to suit your specific needs, and then program them after. Use the tables in the back.

## CENTRAL CONTROLLER FOR CS4™



## General operation

The interrupter button allows you to turn the controller on "I" and off "0" by sliding the button up and down. When the Central Controller is switched off "0", the relay disengages. All settings, including time and date, will be remembered.

The Central Controller is intuitively operated using the navigation

The function of each button is indicated above the button on the display.

## Select room

The initial display allows you to select the room for which you want the actual set temperature and event mode to be displayed. Press "List" and use the left and right arrow to select the desired room.

© 2016 O.I Flectronics A/S @ 2016 O.I Flectronics A/S

#### Back

Various menus and submenus contain a Back option. Use Back to return to the previous step.



## Exit

Returns to the initial display.




## **OPERATION MODE**

The Central Controller features different types of temperature control. Press "Mode" to change the operation mode.

You can always quit the current operating mode and return to the time schedule in progress by pressing "Auto".

## Holiday mode

Select Holiday if you want to lower the temperature in all rooms for a specific period to save energy, e.g. if the house is uninhabited for a period of time.




• Select "Holiday", set the start date and time, the stop date and time, and required temperature for the holiday. Confirm with OK.

The comfort system is now in Holiday mode and a suitcase is displayed. When the period has expired, the system will automatically return to the time schedule in progress.

#### Comfort mode

Select Comfort to set a temporary comfort temperature (so-called party mode) for a single room or all rooms.



The comfort temperature becomes the


highest temperature for the 4-event time schedule for the day


• Press "Comfort", select a single room or "All rooms" and set the hours for comfort mode (1-8 hours). Confirm with OK.

When the period has expired, the system will automatically return to the time scheduled in progress.

## Frost mode

Select Frost to maintain a minimum temperature for frost protection in all rooms.







The system will continue to operate in Frost mode until you return it to the time schedule in progress by pressing "Auto".

## Manual mode

Select Manual to override the time schedule by setting a required temperature manually.





The thermostat will continue to operate in Manual until you return it to the time schedule in progress by pressing "Auto".

## **CENTRAL CONTROLLER MENU**

The Central Controller has several setup menus.

- 4-event settings
- User settings
- Engineer settings
- System settings
- Readout

## 4-event settings: Time schedules

The Comfort System is automatically controlled in accordance with the time schedule of your choice. For each of the 5 time schedules, you can select the settings for different events during the day.

## Factory settings for the time schedules

All the time schedules are ready to use with factory pre-programmed settings for easy and economic heating control.

#### Week schedule:

Factory set to "5:2" - Monday to Friday (Day 1-5) with 4 events and Saturday to Sunday (Day 6-7) with 2 events.

## Mode:

Factory set to "Temperature control".

#### Time and temperature:

Factory set according to the event-schedule below.

## Preset time schedule


Days 1-5 with 4-Event					
Event	Time	With floor-sensor	With room-sensor		
	06:00-10:00	28 °C	21 °C		
Daytime     Daytime	10:00-16:00	20 °C	15 °C		
Evening	16:00-22:00	28 °C	21 °C		
Night	22:00-06:00	20 °C	15 °C		

Days	6-7	with	2-	Eve	nt
------	-----	------	----	-----	----

Event	Event Time		With room-sensor
-X Morning	06:00-22:00	28 °C	21 °C
Night	22:00-10:00	20 °C	15 °C

## Programming of time schedules

You can now adjust the settings in the 5 time schedules to suit the specific needs of the different groups/rooms.



English

Tip! fill in the tables for the time schedules in the back before you start the programming.

## 1. Choose the time schedule

Press Menu/4-event settings/OK.

Press "the name of the zone" and select the time schedule (1-5) to be changed.

## 2. Choose the week schedule

For every time schedule, the 4-event settings follow a specific week schedule. Here, you can choose the type of week schedule required for the group/rooms in the time schedule.

Press Menu/4-event settings/Schedule.

Press "Schedule", select the required week schedule 5:2, 6:1 or 7:0 and confirm with OK.

Monday to Friday with 4 events and Saturday to Sunday with 2 events (this is the factory setting). Typically used if you work from Monday to Friday.

Monday to Saturday with 4 events and Sunday with 2 events. Typically used if you work from Monday to Saturday.

## **"7:0":**

Monday to Sunday with 4 individual events. Allows you to choose individual schedules for each of the seven days of week.

## 3. Choose mode (regulator or temperature)

Allows you to change the type of heating control to be used by the thermostats in this time schedule. NOTE! The time schedule of the relay modules have to be in Temperature mode.

Press "Mode" (Menu/4-event settings/mode), select "Temp" or "Regulator" and confirm with OK.

## Temperature:

Choose "Temp" to set the time schedule for temperature control (this is the factory setting).

The thermostats/relay modules, connected to this time schedule, will now control the heating from the temperature.

#### Regulator:

Choose "Regulator" to set the time schedule to work as a regulator. The thermostats connected to this time schedule now function as a simple regulator and no sensors are used. The setting is a percentage.

NOTE! The thermostats must also be set to regulator mode in their own menu. Go to the menu (SCA ⇒ Hi) and set the application to regulator (App  $\Rightarrow$  C).


If the thermostat is in a different mode than the time schedule. then "E8" will be displayed in the central controller and the thermostat will switch to manual mode.

#### 4. Set time and temperature.


Depending on which week schedule has been chosen, the days of the week are now displayed in the time schedule. You can now set the required time and temperature for every event during the available days.

- Choose the days you want to change (e.g. Tid "Mon-Fri"). Confirm with OK.

- Choose the event you want to change (Morning, daytime, evening or night). Confirm with OK.



- Set the temperatures for this event, first the room temperature and then the floor temperature, and confirm with OK.



⊕ 🌡

User setting

**♦** OK **▶** 

Maks

Now you can program the other time schedules. Select "Back" to go to the list of time schedules, or "Exit" to return to the main screen.

## User setting


In the user settings menu you can change the following:

- · Time and date
- Child lock
- Display settings
- · Energy monitor

## Time and date


Press OK and set the actual time and date. Confirm with OK.

Enable or disable "Daylight saving time" (DST) and confirm with OK.



## Child lock

Allows you to lock the settings, e.g. in public or other places where you do not want the settings changed. There are four alternative child lock settings:



Central: Locks only the central controller.

Normal: Locks all units, including the controller. Individual thermostats can be unlocked locally.


Full: Locks all units, including the controller. Individual thermostats can only be unlocked from the controller.

Off: Disables the child lock settings. Confirm your choice with **OK**. The lock symbol will be shown on the

On the central controller the child lock can be unlocked by simultaneously pressing both the **left** and **right** buttons for 8 seconds.

## Display settings

Choose display setting to be shown on the Main screen.



## Temps:

Choose ether "Set temp", "Room" or "Floor". **Set temp:** Shows the current temperature setting

Room: Shows the actual room temperature Floor: Shows the actual floor temperature

#### Scr. saver (ON/OFF)

Switches off the display after 60 seconds if no button is pressed. Any subsequent press of a button reactivates the display. The controller remains active and runs the selected program.

When Exit is pressed or there has been no activity for 30 seconds, the central controller reverts to the main screen. There are three different modes.

## Single:

Single mode is the standard main screen (Factory setting).


Standard main screen with automatic switching between the current status of all connected room thermostats.

Simple mode for easy mode shifting. The controller will show the main screen in one of the three modes: Holiday, Comfort or Frost. To enter the menu, select **Back** and press **OK**.

Press the **OK** button to select or deselect the display options. Then select Exit in the menu to return to the main screen and view your chosen settings.

## **Energy monitor**

To view the true cost of the energy consumed, select the actual currency and cost per unit.



## Currency:


Press **OK** and choose the required currency. Confirm with **OK**. Cost/unit: Press **OK** and set the actual cost of electricity. The cost must be

entered per kWh. Press OK. To display actual energy consumption and to specify the load for

# **Engineer settings**


The Engineer settings menu contains the following options:

each thermostat, see Readout.




- Adaptive function '
- Application \*
- Temperature scale \* Frost temperature
- Backlight
- Sensor Language
- Factory reset
- Information
- \* Not available if the time schedule of the Central Controller is in regulator mode

© 2016 O.I Flectronics A/S © 2016 O.I Flectronics A/S



## Offset temperature


If the actual temperature (measured using a thermometer) does not correspond to the thermostat value shown on the controller, the thermostat can be adjusted by offsetting the temperature.



Press **OK** and enter the measured temperature value. Confirm with OK.

## Adaptive function

Ensures that the required temperature has already been reached when you get up in the morning or come home from work. After just a few days, the adaptive function will have automatically calculated when the heating



採

Application

OK ▶

must be turned on. The adaptive function applies for all units connected to the system. Press **OK** and set the function.

Press **OK** and set the function to **On**. Confirm with **OK**.

## **Application**

Set the type of control to be used by the Central Controller

Floor: Controls floor temperature

only. A floor sensor must be connected

Room: Controls room temperature only.

Room/limit: Controls room temperature with min, and max, limits


for floor temperature. A floor sensor must be con-

nected.

Press **OK** and select the required application. Confirm with **OK**.

#### Temperature scale


Allows you to set the temperature range within which the Central Controller can be set. It is then only possible to set a temperature within this range in auto, comfort and manual mode.



Press **OK** to highlight **Min** temperature. Use the Up or Down button to select the minimum permissible temperature. Press OK and then select the maximum permissible temperature. Confirm the settings with OK.

## Frost temperature


The required temperature in frost protection mode. Both room and floor temperature can




ture using the Up or Down button. Press OK and set the required floor temperature. Confirm the settings by pressing OK.

## Backlight

There are three settings for the display backlighting:






• Const on: Backlighting is constantly on.

Select the required backlighting setting and confirm with **OK**.

#### Sensor selection

If you are using a sensor with different resistance characteristics than the one supplied with the thermostat, then you need to define the resistance values in this menu.



English


- 1. Select the sensor, from the preprogrammed list: Sensor 2  $k\Omega$ , sensor 10  $k\Omega$ , sensor 15  $k\Omega$ , sensor 33  $k\Omega$  or factory sensor (12 kΩ).
- Confirm or change the resistance values at 15°C, 20°C, 25°C and 30°C for the sensor in use. Confirm with **OK**. The new sensor values are now stored in the controller.
- Select **Information** to see the resistance characteristic of the selected sensor

Note: If an incorrect sensor is selected, there is a risk that the thermostat will not be able to maintain the required temperatures, and damage to the floor construction or covering may therefore occur.

#### Language


Allows the language used on the display to be changed.

Press **OK** and select the required language. Confirm with OK.



#### Factory reset

Allows factory settings to be restored. Your personal settings will be lost, and the connection to all the units will be interrupted. Press **OK** and choose **Reset** in the menu.




Confirm with OK. The Central Controller is now reset.

Go to "First time settings" to restart the system and reconnect the units.

## Information

Here you can find the information for the thermostat, e.g. the software version.



System settings

60

## System settings

The System settings menu contains the following options:

To add a new thermostat or relay module

- Add unit
- · Remove unit
- · Switch unit
- · Alarm relay

Add unit


mode".

## X Add unit to the comfort system, select Add unit and press OK. The controller now enters "listening

For details on connecting the thermostats/relay modules, see Connect thermostats under First time settings.


## Remove unit

To remove a thermostat or relay module from the Comfort System, press **OK**. Select the unit you want to remove and press **OK**. Confirm with OK.



## Switch unit


If a thermostat or relay module has been assigned the wrong time schedule, it can be changed here.



Select the unit concerned and press OK. Now select the required time schedule Confirm with OK.

## Alarm relay

The Central Controller can be used as an alarm relay for external signals from the output terminals. The alarm relay can be set as follows:



Sensor: The alarm relay is activated by sensor faults on one or more of the connected thermostats. Overheat: The alarm relay is activated by sensor faults or

overheating of units.

Communication: The alarm relay is activated by sensor faults, overheating of units or wireless communication faults.

> The alarm relay function is switched off, and the output terminals are used to control an underfloor

heating cable.

## Readout

Off:

The Central Controller features readouts of energy consumption and status for each connected room.



Room status

**♦** OK **▶** 

**\$\$\$** %

Energy monitor


SSS %

- · Energy monitor
- Room status

## **Energy monitor**

Displays energy consumption for the past 2, 30 or 365 days.

Press **OK** and select the room you want to



value in percent (%) shows the relative amount of time the heating has been on. The following figure is the cost for the selected period. To ensure correct calculation, check the settings for Load. Load: Press OK and enter the connected heating power.

The value must be in watt (W). Press **OK**. Leave the menu by pressing Exit.

## Room status

Displays the actual status for each room.

**∀** Signal:

Press **OK** for the chosen room. Signal strength is

> displayed in the top right-hand corner, with up to 4 bars at full

strength

Room: The actual room temperature in degrees. Floor: The actual floor temperature in degrees (if floor or limit control is selected). Application: The application for the actual thermostat.

Operating hours: The number of hours the unit has been switched

ID button: Press ID button to identify the selected Thermostat/relay module. The selected unit will be identified by its ID number in the upper left of the

display in one of the following ways: Thermostat: Display flashes the ID number.

LED flashes as many times as the ID number. The process lasts approx. 10 seconds before the unit returns to

normal mode.

## **CENTRAL CONTROLLER, GENERAL Error messages**

If a fault or error occurs, the Central Controller will display an error code as follows:

E0: Internal failure. The thermostat is defective. Replace unit

E1: Internal sensor defective or short-circuited.

E2: External sensor defective or short-circuited.

E5: Internal overheating. Inspect the installation.

E6: Communication error. No connection to the thermostat or relay

E8: Wrong application. The thermostat is not in the same application as the time schedule from the central controller. Change the application in ether the thermostat (APp) or in the time schedule of the central controller.

## Control signal input

The Central Controller is equipped with a control signal input, the terminal for which is marked "S". By means of an external signal, the thermostat can be controlled in three different modes. See wiringdiagram in the Instruction.

#### Setback:

In setback mode, the thermostat controls the temperature according to the lowest programmed setting in the 4-event schedule for floor and room temperature respectively.

## Frost protection:


In frost protection mode, the thermostat controls room temperature according to the value set under: Engineer settings/Frost tempera-

## Off:

Switches the thermostat to Off.

## THERMOSTAT FOR CS4™

The thermostat is controlled by the central controller of the CS4™. Basic functions such as manual temperature setting and thermostasetup can easily be performed locally on the thermostat. Local setting is displayed with the symbol  $\begin{tabular}{l} \begin{tabular}{l} \begin{$ Other functions such as 4-event timeprogram settings, energy read-



## General operation

The interrupter button allows you to turn the thermostat on "I" and off "0" by sliding the button up and down. When the thermostat is switched off "0", the relay disengages. All settings will, however, be

The thermostat is intuitively operated using the navigation buttons.

## Wireless signal strength

The aerial strenght to the Central Controller is displayed in 1 to 4 bars. 4=Full signal, 1=very low signal.

 $\nabla$  If no aerial bars are shown, there is no connection to the central controller.

If the thermostat is installed far from the controller or there are signal absorbing materials in the building, it may be necessary to

© 2016 O.I Flectronics A/S

© 2016 O.I Flectronics A/S

Comfort System4™ Comfort System4™ English English

use a nearby thermostat with a strong signal and connect it as a repeater, see Repeater function (rEp ⇒ ON).

## Daily use of the thermostat

The thermostat has a temperature setting range from 0 to +40°C. You can define your own limits in the menu "SCA ⇒ High/Low" and "Limit 

High/Low".

## 4-event temperature setting (Auto)

The thermostat will start up using the preset temperature according to the 4-event time schedule from the Central Controller.

#### Change temperature in the central controller.

You can set the time, temperature, week schedule and control mode for in the 4-event time schedules available in the central controller.

## Local-Manual temperature setting 🖔 🛳



Local-Manual allows you to override the 4-event time schedule for the actual event.

#### Set temperature locally.

You change the temperature locally on the thermostat, using the left or right button. The thermostat will then go in "Local-Manual".

- Press the right button to increase the temperature.
- Press the left button to decrease the temperature.
- The temperature flashes for five seconds and then the new setpoint will be shown on the display continuously.

The thermostat will now regulate the heating using this setpoint until the next programmed event in the time schedule starts.

Three waves \$55 will be displayed when the heating is on. You can always cancel local-manual operation, by pressing the middle button. The thermostat will automatically start on the active

4-event time schedule from the central controller.

## Child lock

Allows thermostats in public and other places to be locked, thus preventing unauthorised alteration of the settings. Press and hold the left and right buttons simultaneously for 10 seconds. A "lock" symbol indicates that the thermostat is locked.

The child lock can be released by pressing the left and right buttons simultaneously for 10 seconds.

## THERMOSTAT, SETUP MENU Menu overview

Note. The structure of the menu will vary depending on the setup.

Parameter	Shov	vn o	n display	Factory setting
Max. temperature	SCA	₽	Hi ⇒ 40	40°C (0-40°C)
Min. temperature	SCA	₽	Lo ⇔ 0	0°C (0-40°C)
Max. limit temperature FLOOR	Li	₽	Hi ⇔ 28	28°C (0-40°C + OFF)
Min. limit temperature FLOOR	Li	⇔	Lo ⇔ 15	15°C (0-40°C + OFF)
Measured floor temperature	FLo	$\Rightarrow$	24.5 (exampel)	
Measured room temperature	ro	$\Rightarrow$	21.5 (exampel)	
Application	APp	⇧⇧	F (Floor sensor) A (Room sensor) AF (Room sensor with floor limit) C Regulator %	F : Floor
Adjust	Adj	₽	24.5 (exampel)	Actual tem- peratur (+/- 10°C)
Backlight	LHt	₽	OFF	OFF (OFF/ON)
Address readout	Adr	⇒	01 - 31	
Repeater function	rEp	₽	OFF	OFF (OFF/ON)
Software version	SU	$\Rightarrow$	1.1x	

## Parameters in the setup menu

The menu allows you to view or change the thermostat settings.

- 1. Press and hold the centre button for 3 seconds to activate the menu. SCA will be displayed for 1 second, followed by Hi and finally 40 will appear on the display.
- 2. Press the centre button to go to the next parameter.
- 3. Press the left or right button to change the setting.

If no buttons are pressed for 30 seconds, the program returns to the main screen.

## Max. temperature

The highest temperature to which the thermostat can be adjusted. Min. temperature

The lowest temperature to which the thermostat can be adjusted.

## Max. limit temperature

If a limit/floor sensor is connected to the thermostat, the highest floor temperature allowed for wooden or other floor types can be set

Note. Only available if APp 

AF is selected under Application

#### Min. limit temperature

If a limit/floor sensor is connected to the thermostat, the lowest floor temperature allowed for tiled or other floor types can be set here. 

## Measured floor temperature

Readout of actual floor temperature (if a floor sensor is connected). Note. With no or disconnected sensor, "--" is shown on the display.

## Measured room temperature

Readout of actual room temperature.

Note. With no or disconnected sensor, "--" is shown on the display.

## Application

Depending on which sensor you have for the thermostat, you can select the following temperature control applications.

Thermostat with sensor for:	APp⇒F Floor	APp⇔A Room	APp⇒AF Room/floor limit	APp⇔ C Regulator
Floor	х			x
Room (built-in)		х		х
Room (built-in) and Floor	х	x	x	х

## Floor (F):

The thermostat controls floor temperature only.

Note. Only available if an floor sensor is connected.

## Room (A):

The thermostat controls room temperature only.

## Room/limit (AF):

The thermostat controls room temperature with min. and max. limits for floor temperature.

Note. Only available if an floor sensor is connected.

## Regulator (C):


The thermostat functions as a simple regulator. The floor and room sensors are not used. Heating is controlled on a scale of 0-10, corresponding to 0-100% of full power. (Factory setting: 50%). Note. The time schedule in the central controller must also be set in regulator mode.

#### "Regulator" mode in combination with "Night setback"

The input for night setback can be set to increase or decrease the temperature. The thermostat can also decrease the heating period in % when set to regulator mode.

The setpoint multiplied by the night setback gives the heating period when night setback is activated.





## Adjust

If the actual temperature (measured using a thermometer) does not correspond to the thermostat value, the thermostat can be adjusted by offsetting the temperature.

## Backlight

The display is lit by backlighting whenever a button is pressed. After 30 seconds the light goes out unless a button is again pressed. This menu option allows constant low lighting to be chosen by selecting LHt On.

#### Address readout

Displays the thermostat address.

## Repeater function

If a thermostat or relay module has insufficient or no signal, a second thermostat with strong signal can be configured to repeat the signal. Set the repeater function on the second thermostat to ON and connect the thermostat, see FIRST TIME SETTINGS.

## Software version

Displays the thermostat software version.

## THERMOSTAT. TROUBLESHOOTING Factory reset

Allows factory settings to be restored. Your personal settings will be lost for this thermostat, and the connection to the central controller

- 1. Press and hold the middle button until the display stops flashing and the manual symbol is shown (after 10 seconds). The factory settings are now restored and the thermostat is in manual mode.
- 2. Turn the thermostat OFF and back ON to reconnect to the Central Controller.

## Status messages

Explanation of messages and symbols shown on the display.

Display	Description / Troubleshooting
Con	Connecting to the central controller. Flashes: The thermostat attempts to connect to the central controller.
Adr	Address assigned. Flashes: The central controller and the thermostat will display the assigned address, e.g.
01	"Adr/01".  • Press OK to confirm, otherwise it will flash for 2 minutes.

Display	Description / Troubleshooting
A	Aerial signal with bars. Connection to central controller OK.  • The bars show the signal strength. Full signal = 4 bars. Very low signal = 1 bar.
₹	Aerial signal without bars.  No connection to the central controller. The thermostat will switch to "Local-Manual" mode.  • Check if the central controller is ON, and the unit has not been removed.  • Try to reconnect, or use the repeater from another thermostat.
<ul><li>★</li><li>□•</li><li>□•</li><li>D</li></ul>	<ul> <li>4-events</li> <li>The active event from the central controller is displayed.</li> <li>Morning</li> <li>Daytime</li> <li>Evening</li> <li>Night</li> </ul>
2	Manual mode The thermostat is in manual mode.
*	Frost protection The thermostat is in frost protection mode.
	Holiday mode The thermostat is in holiday mode.
0	Comfort mode / Auto Comfort mode: The clock flashes. Auto: The clock appears and the thermostat follow the active 4-event time schedule.
Image: control of the	Child lock The thermostat is locked in child lock. Press left and right buttons for 10 secunds to unlock.
Ŷ	Local setting Settings has been performed locally.
	Heating ON The relay for the heating is ON.

## **Error messages**

## Error codes, overview

If a fault occurs, the thermostat will display one of the following error


Display	Description / Troubleshooting
E0	Internal fault - Thermostat. The thermostat is defective. • Replace the thermostat.
E1	Built-in room sensor defective.  The built-in room sensor is not working, the thermostat will turn the heating system off.  Replace the thermostat  You can also continue, without the defective sensor, using another application. See overview under "Parameters in the setup menu".

© 2016 O.I Flectronics A/S © 2016 O.I Flectronics A/S Comfort System4<sup>™</sup> English Comfort System4<sup>™</sup> English

Display	Description / Troubleshooting
E2	External wired floor sensor defective. The external floor sensor is not working, the thermostat will turn the heating system off.  Replace the floor sensor and/or the cable You can also continue, without the defective sensor, using another application. See over-
E5	view under "Parameters in the setup menu".  Internal overheating - Thermostat. The thermostat is not working, and the heating system is off.  • Check that heating cables are not overloaded.  • Check that ambient temperature is not excessive.  • When internal temperature drops, the thermostat automatically reactivates.
E8	Wrong application - CS4.  The thermostat is not in the same application as the time schedule from the central controller.  Change application in the menu (APp). See overview under "Parameters in the setup menu".

## RELAY MODULE FOR CS4™

Relay module for controlling electric heating panels, etc., featuring night setback, frost protection and floor sensing thermostat mode. Only for use in combination with the MCS4-10 Central Controller for wireless communication.



## General operation

The interrupter button allows you to turn the Relay module on "I" and off "0" by sliding the button up and down. When the Relay module is switched off "0", the relay disengages. The wireless settings will be remembered.

The two LED on the front indicate actual status.

## Application

The relay module can be used for three different control types: Night setback, Frost protection or with an external floor sensor. The type is determined by the way in which the relay module is wired and configuration occurs automatically.

## Night Setback:

The relay module lowers the temperature according to the selected time schedule (Connect the heating panel to terminal 4).

## Frost protection:

The relay module enters frost protection mode if chosen on the Central controller (Short-circuit terminals 5 and 6 then the relay module uses the built-in room sensor)

## Thermostat with external sensor:

The relay module controls the temperature according to the selected 4-event time schedule in the central controller (connect a floor sensor to terminals 5 and 6).

## **Error massages, LED readouts**

The relay module has a green and a red LED to indicate actual status.

Green ON:	Power ON,	Power ON, Relay module OK.		
Green flashes	Connection	Connection sequence in progress		
quickly:				
Green flashes	No connect	No connection to Central Controller		
slowly:				
Red ON:	Relay ON, p	Relay ON, power to heating source		
Red flashes	Error code.	Error code.		
quickly:	1 flash	1 flash E1: Internal sensor defective or		
		short-circuited.		
	2 flashes	E2: External sensor defective or		
		short-circuited		
	5 flashes	E5: Internal overheating. In-		
		spect the installation.		
	6 flashes	E6: Communication error		

## **Factory reset**

Controller.

Allows factory settings to be restored and cancels the connection to the Central Controller.

- Remove the cover by inserting a small screwdriver into the hole on one side of the thermostat.
- Now hold the screwdriver on the contact points under the LEDs. Hold it until both LEDs flash three times.
- The relay module has now been reset.

  3. Mount the cover and turn the power off and on again. The relay module will now connect to the Central

## **HOW TO PLAN YOUR SYSTEM**

All the units connected to the Central Controller, need to have a time schedule assigned.

- 1. Name the time schedules in your system. Choose up to 5 names from the zone-list below.
  - You can have many thermostats using the same time schedule/name.
- Fill out the tables for the time schedules, this gives you a good overview of your system.
- Program the time schedules in the Central Controller. Go to "Programming of time schedules" (Menu/4-event settings/OK).

## Zone-list, names for time schedules

Choose the names for your groups of thermostats with the same time schedule (max. 5 names can be chosen).

Note. The names may vary depending on the model.

Living Areas	Bathroom	Kitchen
Mast.Bedroom	Bedroom 1	Bedroom 2
Bedroom 3	Bedroom 4	Mast. Ensuite
Ensuite 1	Ensuites	WC
Dining Area	Formal Dining	TV Room
Shower Room	Bath/ES/WC	Utility
Study	Bedrooms	Gvm

## Table for time schedules

Group the thermostats in your house together into different time schedules.

See example below.

Name	Living Areas		
Mode	Temp <del>or regulator</del>		
Week Schedule	5:2, <del>6:1 or 7:0</del>		
Time and tem	•	setting pr. event (in	%)
Days with 4-Event	Start	Temp. Floor (°C)	Temp. Room (°C)
Days with 4-Event	(time)	*Regulator (%)	
Morning	06:00	25	21
Daytime	08:00	20	15
Evening	16:00	25	21
Night	23:00	20	15
Days with 2-Event	Start	Temp. Floor (°C)	Temp. Room (°C)
	(time)	*Regulator (%)	
Morning	08:00	25	21
Night	23:00	20	15

Rooms / Thermostats
ID and description
Adr. 00 - Living room, downstairs
Adr. 03 - Dining room, downstairs
Adr. 05 - Living room, upstairs
Adr. 07 - Dining room, upstairs

Week Schedule	5:2, 6:1 or 7:0		
Time and temp *In regulator mode you		e setting pr. event (in	%)
Days with 4-Event	Start	Temp. Floor (°C)	Temp. Room (°C
Days Will 4-Everit	(time)	*Regulator (%)	
Morning			
Daytime			
Evening			
Night			
Dave with 0 Event	Start	Temp. Floor (°C)	Temp. Room (°C
Days with 2-Event	(time)	*Regulator (%)	
Morning			
Night			
Doomo / Thousa	a a atata	•	•
Rooms / Thern ID and description	แบรเสเร		
ib and description			

Name			
Mode	Temp or regulator		
Week Schedule	5:2, 6:1 or 7:0		
Time and tem	nperature ou only have on	e setting pr. event (in	%)
Days with 4-Event	Start	Temp. Floor (°C)	Temp. Room (°C
Dayo Will 1 Evolic	(time)	*Regulator (%)	
Morning			
Daytime			
Evening			
Night			
Days with 2-Event	Start	Temp. Floor (°C)	Temp. Room (°C
Days with 2-Everit	(time)	*Regulator (%)	
Morning			
Night			
Rooms / Thei	rmostats		

	Temp or regula	tor
	5:2, 6:1 or 7:0	)
perature ou only have on	e setting pr. event (in	%)
Start	Temp. Floor (°C)	Temp. Room (°C)
(time)	*Regulator (%)	
Start	Temp. Floor (°C)	Temp. Room (°C)
(time)	*Regulator (%)	
mostats		
	perature ou only have on Start (time)  Start (time)	perature ou only have one setting pr. event (in Start Temp. Floor (°C) (time) *Regulator (%)  Start Temp. Floor (°C) (time) *Regulator (%)

© 2016 OJ Electronics A/S

Name			
Mode	Temp or regulator		
Week Schedule		5:2, 6:1 or 7:0	)
Time and tem		e setting pr. event (in	%)
Dava with 4 Event	Start	Temp. Floor (°C)	Temp. Room (°C)
Days with 4-Event	(time)	*Regulator (%)	
Morning			
Daytime			
Evening			
Night			
Days with 2-Event	Start	Temp. Floor (°C)	Temp. Room (°C)
Days Willi 2-Lvelit	(time)	*Regulator (%)	
Morning			
Night			
Rooms / Thei	rmostats		

Temp or regulator		
5:2, 6:1 or 7:0		
an a watu wa		
	setting pr. event (in	%)
Start	Temp. Floor (°C)	Temp. Room (°C)
(time)	*Regulator (%)	
Start	Temp. Floor (°C)	Temp. Room (°C)
(time)	*Regulator (%)	
rmostats		
	nperature ou only have one Start (time)	5:2, 6:1 or 7:0  pperature ou only have one setting pr. event (in     Start Temp. Floor (°C)     (time) *Regulator (%)  Start Temp. Floor (°C)     (time) *Regulator (%)



OJ ELECTRONICS A/S Stenager 13B · DK-6400 Sønderborg Tel.: +45 73 12 13 14 · Fax +45 73 12 13 13 oj@ojelectronics.com  $\cdot$  www.ojelectronics.com